

F O R D E S P
PREMIUMCARE
 EXTENDED SERVICE PLANS



Service at all Ford and Lincoln Dealers in the U.S. and Canada



100% Backed by Ford Motor Company

– The only Extended Service Plan backed by Ford Motor Company



Limit Out-of-Pocket Expenses

– On covered repairs, you pay only the applicable deductible



Genuine Ford Parts and Service

– Repairs are made with genuine Ford parts by factory-trained and certified technicians



24-Hour Roadside Assistance

– Includes tire change, lockout, out-of-fuel, battery jump-start and towing assistance of up to \$100 per occurrence, Travel Expense Reimbursement (up to \$500 and three days per occurrence) and Destination Assistance (up to \$75)
 – For 24-hour roadside assistance, call **1-800-241-3673** toll-free



Rental Vehicle Benefits

– Provides coverage for up to 10 days of rental for a covered repair



Coverage Is 100% Transferable

– Ford ESP is transferable and may increase the resale value if you sell your vehicle



Interest-Free Payment Option

– Finance your coverage in monthly installments with no interest or fees; everyone qualifies



PremiumCARE is
 our most comprehensive
 service plan coverage to
 protect you from unexpected
 vehicle repair costs.



Extended Service Plan

1,000+
 Key Components Covered
 For New and Used Vehicles

This brochure is intended to provide general information about Ford ESP. Prices and plans are subject to change without notice. Plan availability, benefits, coverage and provider may vary by state. See your dealer for details.

In Florida, Ford ESP on Ford, Lincoln and Mercury vehicles is a Service Contract from Ford Motor Company (License #12118). Ford ESP on competitive-make vehicles is a Service Contract from The American Road Insurance Company, Dearborn, MI 48126 (Certificate of Authority #09079).

In Texas, Ford ESP is a Service Contract from Ford Motor Service Company (License #SCP-165).

14ESP-PCBRCH-F
 64172_269b

Printed in U.S.A.

October 2013

PremiumCARE Is the Most Comprehensive Service Plan Protection Offered by Ford Motor Company



It covers the parts and labor to repair thousands of key components – engine, transmission, steering, brakes, front suspension, electrical and more – **for up to 7 years or 125,000 miles.**

Failure of covered components due to defects in materials and workmanship and normal wear and tear are included. **With Ford ESP PremiumCARE, it's covered.**

Why Ford Extended Service Plan (ESP) PremiumCARE Is a Great Value ...

The price for parts and labor to repair many major components can be significant. One repair bill can easily exceed the price of your Ford ESP coverage. It's clear that this coverage can quickly pay for itself!



Estimated expenses for a variety of repairs are listed above and should only be used as an example. Actual costs will vary by vehicle, repair and dealer location.

*Wear item.

Ford ESP Coverage Options

A variety of time/mileage options and deductibles are available:

NEW PLAN TIME AND MILEAGE OPTIONS (Available within New Vehicle Limited Warranty)					
Miles	3 Years	4 Years	5 Years	6 Years	7 Years
36,000			■	■	■
48,000	■	■	■	■	■
60,000	■	■	■	■	■
75,000	■	■	■	■	■
100,000	■	■	■	■	■
125,000	■	■	■	■	■

USED PLAN TIME AND MILEAGE OPTIONS	
Coverage lengths range from 12 months/12,000 miles to 60 months/75,000 miles for 2003 and newer vehicles. Ask your dealer for specific plan availability.	

DEDUCTIBLE OPTIONS		
	STANDARD	OPTIONAL
New Ford and Competitive-Make Vehicle Plans	\$100	\$0, \$50, \$200, Disappearing
Used Ford and Competitive-Make Vehicle Plans	\$100	\$50, \$200, Disappearing

For New Plans:

- Coverage begins with the original in-service date (New Vehicle Limited Warranty start date) and zero miles. Coverage expires upon reaching your selected time, mileage or hours, whichever occurs first.

For Used Plans:

- Coverage for Ford, Lincoln and Mercury vehicles beyond the New Vehicle Limited Warranty and all competitive-make vehicles begins at the signature date and current mileage and expires upon reaching your selected time or mileage, whichever occurs first.
- Eligible Ford, Lincoln and Mercury vehicles that have New Vehicle Limited Warranty remaining at the time of purchase – coverage begins at the signature date and current mileage/hours. Coverage ends at the earlier of the number of months purchased or the number of miles/hours purchased from the expiration of the New Vehicle Limited Warranty.

For Cab & Chassis Vehicles:

- A variety of unique time/mileage options and deductibles are available within 5 years and 100,000 miles of the original in-service date. See your dealer for details.
- Coverage begins with the original in-service date (New Vehicle Limited Warranty start date) and zero miles. Coverage expires upon reaching your selected time, mileage or hours, whichever occurs first.

PremiumCARE 1,000+ Covered Components



ENGINE

- All Internally Lubricated Parts
- Cylinder Block
- Cylinder Heads
- Diesel Fuel Injectors
- Diesel Injector Lines
- Diesel Injector Pump
- Diesel Lift Pump
- Engine Mounts
- Flywheel
- Flywheel Ring Gear
- Fuel Tank and Metal Lines
- Gas Fuel Injectors
- Gas Injector Lines
- Harmonic Balancer and Bolt
- Manifold and Bolts
- Manifold (Exhaust and Intake)
- Oil Pan
- Oil Pump
- PCM Module
- Radiator
- Radiator Fan (Clutch or Motor)
- Seals and Gaskets
- Thermostat
- Thermostat Housing
- Timing Chain Cover
- Timing Chain (Gears or Belt)
- Turbocharger/ Supercharger Unit (Factory-Installed)
- Valve Covers
- Water Pump



TRANSMISSION

- All Internally Lubricated Parts
- Release Hubs and Bearings
- Seals and Gaskets
- Torque Converter
- Transfer Case (Including All Internal Parts)
- Transmission Case
- Transmission Linkage
- Transmission Module (External)
- Transmission Mounts



REAR-WHEEL-DRIVE AXLE

- Axle Shafts
- Bearings (Front and Rear)
- Drive Axle Housing and Front Axle Housing for 4x4 (Including All Internal Parts)
- Driveshaft
- Retainers
- Seals and Gaskets
- Universal and Constant Velocity Joints



FRONT-WHEEL-DRIVE AXLE

- Axle Shafts
- Bearings (Front and Rear)
- Final Drive Housing and Rear Axle Housing for AWD (Including All Internal Parts)
- Hubs, Automatic Front Locking (Four-Wheel Drive)
- Locking Rings (Four-Wheel Drive)
- Seals and Gaskets
- Universal and Constant Velocity Joints



STEERING

- Column Lock (Tilt Wheel)
- Control Valve
- Cooler and Metal Lines
- Electronic Power Assisted Steering
- Idle Arm
- Power Steering Pump/ Electric Power Steering Actuator
- Pulley Assembly
- Seals and Gaskets
- Steering Column
- Steering Gear Housing, Manual and Power (Including All Internal Parts)
- Steering Shaft
- Underbody Linkages and Couplings



BRAKES

- Anti-Lock Brake Module and Sensor
- Backing Plates
- Brake Booster (Power)
- Calipers
- Combination Valve
- ETA Pump Hose Assembly
- Metal Lines and Fittings
- Master Cylinder
- Parking Brake Linkage and Cables
- Retainers and Clips
- Self-Adjusters
- Shaft (Brake Pedal)
- Springs
- Wheel Cylinders



FRONT AND REAR SUSPENSION

- Ball Joints (Upper and Lower)
- Control Arms (Upper and Lower)
- Control Arm Shafts and Bushings
- Kingpins and Bushings
- Linkage and Bushings
- Load Leveler Suspension System
- MacPherson Struts
- Roll Stability Control
- Spindle and Spindle Support Springs
- Stabilizer Bar
- Tie Rods



ELECTRICAL

- Alternator
- Audiophile Sound System
- Charge and Volt Gauges
- Clock (Electric)
- Control Trac 4WD System
- Driver's Seat Position Sensor
- Dual-Zone Electronic Automatic Temperature Control
- Electronic Ignition Module
- Fuel Pump
- Heated Backglass (Electrical Only – Not Glass Damage or Breakage)
- Ignition Coil
- Ignition Lock
- Ignition Module (Electric)
- Ignition Switch
- Intelligent 4WD Systems
- Power Mirrors (Electrical Only – Not Mirror or Glass Damage or Bulbs)
- Power Running Boards
- Radiator Fan Relay
- Rear Window Power Sunshade
- Speedometer/Odometer (Electrical and Mechanical)
- Starter Motor
- Starter Motor Solenoid
- Switches (Manually Operated Electrical)
- Temperature Gauge
- Voltage Regulator
- Wiper-Activated Headlamps
- Wiper Motors
- Wiring Harnesses (Excluding Spark Plug Wires)



AIR CONDITIONING AND HEATING

- A/C Accumulator
- A/C Clutch
- A/C Clutch Bearings
- A/C Compressor
- A/C Compressor Clutch Switch
- A/C Compressor Head
- A/C Compressor Seals
- A/C Condenser
- Auto Temp Control
- Evaporator
- Field Coil
- Heater Blower Motor
- Heater Control Assembly
- Heater Core Assembly
- Instrument Panel Registers and Air Ducts
- Pulley



HIGH-TECH

- Adaptive Cruise Control
- Adaptive Headlamp System (Excluding Lamp Housing, Bulbs)
- Air Suspension (Selected Electronic Components)
- Anti-Theft Alarm (Factory-Installed)
- Auto Lock and Auto Unlock System
- Automatic Park Assistant
- FordLink™ System
- Ford Work Solutions Asset Security (if equipped)
- Forward Sensing Sys
- Fuel Mixer (Alternative)
- In-Dash Garmin™ Voice-Activated Navigation System (Factory-Installed and Dealer)
- Instrument Cluster (Excluding Dash Pad)
- Intelligent Oil Life Monitor System
- Keyless Entry System (Excluding Door Handles)
- Message Center
- Parallel Park Assist Sys
- Power Antenna
- Power Door Locks and Retainer Clips (Excludes Door Handles)
- Power Seat Motors
- Power Window Motors/Regulators
- Rain-Sensing Wipers
- Rear Console Refrigeration
- Reverse Camera Sys
- Reverse Sensing Sys
- SecuriCode™ Keyless Entry
- SecuriLock® Passive Anti-Theft Ignition System
- Sensor (Alcohol)
- SOS Post-Crash Alert System
- Speed Control
- Stationary Elevated Ride Control
- SYNC MyFord Touch (Excludes Software Upgrades)
- Trailer Brake Module
- Unique Hybrid/Electric Vehicle Components (Excluding High-Voltage Battery and Cables)



EMISSIONS

- Air Check Valve Assembly
- Air Control Valve
- Air Idle Vacuum Valve
- Air Supply Valve (Hose and Tube)
- Barometric Pressure Sensor
- DEF System (Excludes Catalyst)
- ECC Relay Assembly
- EGR Control Valve
- EGR Pressure Sensor
- EGR Regulator Assy
- EGR Valve Adapter
- Electronic Throttle Cntrl
- EVAP Vapor Storage Canister
- Idler Air Control Valve
- Knock Sensor
- Mass Air Flow/Intake Air Temp Sensor
- Oxygen Sensor
- PCV Hose Assembly
- PCV Valve
- PCV Vapor Filter
- Reductant Urea System
- Temperature Sensor (Engine Coolant)
- Vacuum Restrictor
- VAF Sensor
- Variable Camshaft Timing (VCT) Phasers



AUDIO

- Antenna, Radio (Base Assembly)
- Brackets
- Cables and Wiring
- Cellular Phone, Receiver, Handset, Speaker Assembly and Antenna (Factory-Installed)
- Compass and Therm Readout Displays
- Controls (Rear Seat)
- Radio (AM, AM/FM), Speakers, Cassette Player, Digital CD Player, Graphic Equalizer, Premium Sound Amplifier (Factory-Installed)
- Rear Entertainment System (Factory-Installed)



SAFETY

- Airbag Module Assembly
- Blind Spot Info Sys (Electrical Only – Not Mirror or Glass Damage or Bulbs)
- Collision Avoidance
- Cross Traffic System
- Diagnostic Module Assembly (Airbag)
- Door Ajar Warning Switch Assembly
- Guides, Bezels, Brackets and Supports (Safety Belts/Shoulder Straps)
- Head Restraint Retainers and Sleeves (Safety Belt)
- Key, SecuriLock® (Microchip-Encoded Key)
- Lane Depart Warning
- Lock Cylinder (Door)
- Lock Lever Assy (Door)
- Lock Lever Assembly (Tailgate)
- Lock Lever Retainers, Clips and Brackets
- Module (Passive Restraint)
- Safety Belt Buckle (Front and Rear)
- Safety Belt Motor Drive Assembly
- Safety Belt Restraint Carrier
- Safety Belt Retractors
- Safety Belt Track Asy
- Safety Belt Warning Chime Assembly
- Safety Canopy
- Sensors (Airbag)
- Shoulder Strap Track Assembly
- Wiring Asy (Airbag)

Certain restrictions and exclusions apply. See your dealer for details, or refer to your plan provisions. The 1,000+ covered components include, but are not limited to, the components listed in this brochure.

PremiumCARE is so comprehensive, it's easier to tell you what isn't covered:

Generally Covered by Auto Insurance

Bumpers, glass, moldings, ornamentation, paint, sheet metal, structural underbody framework, sideview mirrors (glass and housing), rearview mirror (glass and housing), wheel covers, studs and ornaments, service adjustments (glass and body parts), convertible top and wheels

Owner Maintenance Requirements

Service adjustments and cleaning, software upgrades, fixed (non-moving) body parts, batteries of all types and cables, belts, hoses, hose clamps, brakes (front hub, drums, shoes, linings, disc rotors, pads), manual transmission clutch disc, coolant, exhaust system (including catalytic converter), filters, fluids, lubricants, lights (bulbs, sealed beam, lenses), spark plugs, spark plug wires, squeaks and rattles, tires, tune-ups, wheel balancing, wheel alignment, LED lights, shock absorbers and compressed natural gas/liquid propane fuel system conversion components

Components and Repairs Not Covered by PremiumCARE

Buttons, carpet, clamps, dash pad, door and window handles, knobs, trim, upholstery, CNG/LPG components, tires, water leaks, wind noise, weatherstrips, fabric, liners, zippers and fasteners