

SuperDuty Power Stroke® Engine Plans



Extended Service Plans for SuperDuty Vehicles with Power Stroke® Engines

Diesel EngineCARE 6.0, 6.4 and 7.3 Liter

7-Year/200,000-Mile Coverage

13 Covered Components:

- Internal Lubricated Parts
- Cylinder Block
- Cylinder Heads
- Oil Pump
- Timing Chain Cover
- Timing Chain (Gears or Belt)
- Turbocharger (Factory Installed)
- Cylinder Head Gasket
- Crankcase Oil Cooler
- FGR Cooler
- Fuel Injection Pump
- Fuel Injection Pressure Regulator
- Fuel Injectors

Diesel EngineCARE Plus 6.0, 6.4 and 7.3 Liter

7-Year/200,000-Mile Coverage

21 Covered Components:

- Internal Lubricated Parts
- Cvlinder Block
- Cylinder Heads
- Oil Pump
- Timing Chain Cover
- Timing Chain (Gears or Belt)
- Turbocharger (Factory Installed)
- Thermostat
- Thermostat Housing
- Water Pump
- Fuel Injectors

- Flywheel
- Manifold (exhaust and intake)
- Manifold and Bolts
- Oil Pan
- Seals and Gaskets*
- Valve Covers
- Crankcase Oil Cooler
- EGR Cooler
- Fuel Injection Pump
- Fuel Injection Pressure Regulator

*Includes Cylinder Head Gasket

Diesel EngineCARE and Diesel EngineCARE Plus both feature:

\$0 Deductible

Roadside Assistance Benefits:

- Flat tire change
- · Battery jump starts
- Towing when the vehicle is disabled (limited to one tow per disablement)
- Lock-out assistance
- Out of fuel assistance delivery of up to five (5) gallons of diesel fuel
- Travel expense reimbursement up to \$500 for up to three days lodging, meals and rental vehicle for travel expenses accrued when the breakdown occurs 100 miles or more from home
- Destination assistance covers taxi, shuttle or rental car expense up to \$75 for emergency transportation to the immediate destination
- Call 1-800-241-3673 to obtain roadside service from Ford Auto Club

Coverage Includes:

- Coverage includes repair or replacement of covered components for the time and mileage period you select. Parts and labor are included
- Failure of covered components due to normal wear resulting from defective material or workmanship are included, in addition to mechanical breakdowns
- Coverage expires at the number of months or miles purchased from the warranty start date or zero miles, whichever comes first

Transferrable

